


Warning!

A wrong connection will destroy the module. For connection, the ribbon cable (16-pin socket) is connected to the system bus board.



The red mark (-12V) must point down on the system bus board.

Never connect a module while the system is receiving power.

